

## **BROAD 100 - PROJECTOR INSTRUCTIONS**

**PLEASE NOTE: THIS PROJECTOR IS A DLP, NOT  
AN LCD SO THE PROJECTION COULD APPEAR  
TO BE “FUZZY”**

**ADJUST THE RESOLUTION ON YOUR LAPTOP  
TO:**

**1024x768 with a refresh rate less than 76 Hz**

**DOING THIS WILL GIVE YOU THE BEST  
RESULTS WITH THIS PROJECTOR**

**BE SURE TO TURN OFF THE PROJECTOR  
BEFORE LEAVING THE ROOM!!!**

**THANK YOU.**